## TIRE SPREADER Pranick **5120**



## Versatile and easy to use spreader!

The Model 5120 is typically used for both passenger and light truck tires when you need a little more from a spreader. It is air powered, easy on the operator and your bottom line. It comes with a convenient tool tray that can be mounted on either side of the spreader. The stable 4-point base can be bolted to the floor and there's a

foot control valve for spreading the tire, which also gives you a stable work surface. There is an easy spring-loaded adjustment and the high-impact industrial light is mounted on a flexible arm making it easier for inspection and repair. It uses a CFL bulb that is RMA compliant, meaning our bulbs emit a minimum of 200 foot candles, which the RMA requires for proper tire repairs. Made in the U.S.A. at Branick's manufacturing facility in Fargo, ND!



\*Branick bulbs emit a minimum of 200 foot-candles. which is requred for tire repair.

## **FEATURES**

BENEFITS Handles everything from passenger to truck tires......Well-rounded spreader for busy shop

Tool tray can be mounted on either side......For easy accessibility

Foot-control valve for spreading......Quick, hands-free spreading and stable

work surface

Spring loaded adjustment...... Ease of use; all parts contained

High impact industrial light on flexible arm.....Easy inspection and repair; RMA Compliant

## **SPECIFICATIONS**

Handles passenger and light truck tires up to 20"

Watch the video with your SmartPhone!

www.branick.com 4245 Main Ave. PO Box 1937 Fargo, ND 58107 Phone: 800.437.4394 Fax: 701.281.5900

<sup>&#</sup>x27;See manual for details.